



—
INSTALLATION INSTRUCTION

Auxiliary contact

OA1G01-OA1G10, OA7G10, OA8G10




Auxiliary contacts











A00187A

Auxiliary contacts




A00187B


OA1G10-OA3G01



OA1G10-OA3G01, OA5G10-OA6G01



OA1G10-OA3G01





Contact us

ABB Oy

Muottitie 2A 65320

Vaasa Finland

abb.com/lowvoltage