

ACAL series : Instructions for installation

Anchoring clamps for Fig-8 cables installed on short and medium spans (120 m max.)



Attach the clamp to the pole bracket using its flexible bail.
Lock the bail ends onto the dedicated ears.



Place the clamp body over the cable with the wedges in their back position.

Continue >>



Push on the wedges by hand to initiate the gripping onto the cable.



Check the correct positioning of the cable between the wedges.
Make sure that the wedges grip the messenger part only.



When the cable is brought to its installation load at the end pole, the wedges move further into the clamp body.

When installing a double dead-end leave some extra length of cable between the two clamps.