



|                                                             |                                         |
|-------------------------------------------------------------|-----------------------------------------|
| Earth-leakage protection sensitivity adjustment type IΔn    | Justerbar 9 innstillinger               |
| [IΔn] earth-leakage protection sensitivity adjustment range | 0,5...30 A                              |
| Jordfeil følsomhet                                          | 10 A for A-klasse<br>30 A for klasse AC |
| Earth-leakage protection time delay adjustment              |                                         |