

Description



- Switching programs created on the PC by means of the convenient OBELISK top2 software can be transferred via USB interface to the OBELISK top2 memory card and from the card to the time switch and vice versa. Thus no PC or laptop is required on-site. Programming and the program printout can be done comfortably from the desk
- Consisting of: Memory card, USB plug adapter, software
- Updates of existing OBELISK top2 software are available as free downloads at www.theben.de