



VR5

Monteringsanvisning
Monteringsvejledning
Monteringsanvisning
Инструкция за монтаж


Asennusohjeet
Montageanweisung
Installation instructions

N DK S
FIN D GB
BG


1a.




1b.




	L	1 (min.)	2	3	4 (max.)
VR 505	440 mm	100W	200W	300W	500W
VR 507	605 mm	150W	300W	450W	750W
VR 510	740 mm	200W	400W	600W	1000W




2.



3.



4.



5.

Elektrisk montasje må bare utføres av autorisert installatør.

Elektrisk montage må kun udføres af autoriseret el. installatør.



Електрическото свързване трябва да се извърши от оторизиран електротехник.

Elektrisk installation får endast utföras av behörig installatör.

Sähköasennukset saa suorittaa vain asennusoikeudet omaava asennusliike.

Anschluß darf nur durch Fachmann durchgeführt werden.

Electric installation must be carried out by an authorised electrician.



YE/GN	Gul/grønn	Gul/Grøn	Gul/Grön	Kelta/Vihreä	Gelb/Grün	Yellow/Green	Жълто/Зелен
WH	Hvit	Hvid	Vit	Valkoinen	Weiß	White	Бял
BU	Blå	Blå	Blå	Sininen	Blau	Blue	Син
BN	Brun	Brun	Brun	Ruskea	Braun	Brown	Кафяв

Bruk
Brug
Användning
Käyttö
Bedienung
Use
Употреба




Art. nr. 62327 05/19


VR5

Bruksanvisning
Brugsanvisning
Bruksanvisning
Инструкция за употреба

Käyttöohjeet
Bedienungsanleitung
Instruction for use




1.



230V, 50Hz, IP44

2.




3.



Oljerøk, i ca. 5 min.
Olierøg, maks. 5 min.
Oljerøk, i ca. 5 min.
Öljynkatkua, enintään 5 min.
Öl verdunste, Max. 5 Min.
Oil fumes, max. 5 min.
Маслени испарения, 5 мин.

4.



Rengjøres hver måned i fyringssesongen
Rengøring hver måned i opvarmningssesonen
Rengörs varje månad under användningsperioden
Puhdistetaan kuukausittain käyttöaikana
Reinigung, 1x im Monat während der Heizperiode
Clean each month during period of use
Почиствайте всеки месец през периода на употреба

Montering
Montering
Montering
Asennus
Montage
Installation
Монтаж

