

LEDDim Smart Pill Mini



230V, 50/60Hz, -20°C to 35°C Operating frequency: 2402-2480MHz, Maximum radio-frequency output power: 2dBm

LEDDim App





Android OS 5.1, Ram 2.5GB mid-range CPUs<



iOS 9.0, iPhone 5s<




<http://www.sg-as.no/leddim/getapp/>




NO: Impulsbryter (valgfritt)
EN: Push button (optional)
FR: Bouton-poussoir (optionnel)
NL: Drukknop (optioneel)
DE: Druckknopf (optional)
FI: Painonappi (valinnainen)

Max. 200W	Max. 160W	Max. 160W	



NO: Minimum dimmenivåjustering
DA: Minimum justering af dæmpningsniveau
SE: Minsta justering av dimningsnivå
EN: Minimum dimming level adjustment
FR: Réglage du niveau de gradation minimal
NL: Regelbaar niveau van minimale dimmingsgraad
DE: Anpassung der minimalen Dimmstufe
FI: Minimi himmennystaso

Reset ↺



NORWAY

SG Armaturen AS

Skytterheia 25
N-4790 Lillesand

Tel: +47 37 50 03 00
firmapost@sg-as.no
www.sg-as.no

SWEDEN

SG Armaturen AB

Tel: +46 31 81 71 10
info@sg-ab.se
www.sg-ab.se

FINLAND

SG Armaturen Oy

Tel: +358 02 07 30 39 60
info@sg-oy.fi
www.sg-oy.fi

DENMARK

SG Armaturen A/S

Tel: +45 70 70 72 13
info@sg-as.dk
www.sg-as.dk

UNITED KINGDOM

SG Lighting LTD

Tel: +47 37 50 03 00
info@sglighting.co.uk
www.sglighting.co.uk

FRANCE

SG Lighting SA/NV

Tel: +33(0) 4 94 93 00 00
info.france@sglighting.fr
www.sglighting.net

BENELUX

SG Lighting SA/NV

Tel: +32(0) 15 20 72 71
info.benelux@sglighting.net
www.sglighting.net

GERMANY

SG Leuchten GmbH






Tel: +49 40 23 99 44 59
info@sg-leuchten.de
www.sg-leuchten.de

INTERNATIONAL




SG Lighting Co Ltd.

Tel: +86 769 88 49 20 88
cindy@sgdgc.com
www.sg-as.com

Rev: 30.06.2022



Pairing



NO: Kan kun installeres og vedlikeholdes av en registrert installasjonsvirksomhet.

DK: Må kun installeres og vedligeholdes af uddannet elektriker.

SE: Skall installeras och underhållas av behörig elektriker.

EN: Only to be installed and maintained by an authorized electrician.

FR: Doit être installé et maintenu par un électricien qualifié.

NL: Mag alleen geïnstalleerd en onderhouden worden door een bevoegde elektricien.

DE: Dieses Produkt darf nur durch autorisiertes Personal (z.B. Elektro-Installateur) angeschlossen, in Betrieb genommen und gewartet werden.

FI: Asentaa ja huoltaa saa vain valtuutettu sähköasentaja

NO: Skru av strømmen før montering.

DK: Sluk for strømmen inden montering.

SE: Stäng av strömmen innan montering.

EN: Turn off power before installing.

FR: Couper le courant avant l'installation.

NL: Stroom uitschakelen voor u het toestel installeert.

DE: Vor Installationsarbeiten den Strom abschalten.

FI: Sammuta virta ennen kytkemistä